



**FEATURES**

- User Selectable Trip Time
- Auto/Manual/ZVR Reset Function
- True RMS Measurement

**Protection Available**

- Over/Under Voltage
- Over/Under Current
- Over/Under Frequency
- Single Phase Prevention
- Short Circuit
- Unbalance
- Phase Loss
- Lock Rotor Point
- Phase Sequence
- Neutral Loss

**TECHNICAL SPECIFICATION**

**INPUT:**

Voltage AC	
Direct Voltage AC	30 to 300V(L - N) 50 to 520V(L - L)
Burden	< 0.2VA
Current AC	
Primary CT Ratio	5 to 6000 Amp selectable
Secondary Current AC	0.1 to 5 Amp
Burden	< 0.2VA
Overload	Up to 6A continuous
Frequency	45.0 to 65.0 Hz

**DISPLAY AND KEYS:**

Display	3 Digit, 3 Line 7 Seg 0.56", RED LED
Keys	Scroll, SET, RST, INC, DEC

**DIMENSION:**

Size (mm)	96 (H) X 96 (W) X 53 (D) mm
Panel Cutout (mm)	92 (H) X 92 (W) mm

**NETWORK SELECTION:**

3 Phase - 4 Wire, 3 Phase - 3 Wire
------------------------------------

**TRIP SETTING:**

Under Current	0.00 to CTR
Over Current	0.00 to CTR
Under Voltage	50 to 520V For 3Ø - 3W 30 to 300V For 3Ø - 4W
Over Voltage	50 to 550V For 3Ø - 3W 30 to 330V For 3Ø - 4W
Over / Under Frequency	45.0 to 65.0 Hz
Short Circuit	1 - 9 Scale
Lock Rotor Point	0.5 to 9.0 Scale
Unbalance	5 - 60%

**TIME PARAMETER:**

Power On Delay	0 to 99 Sec
Initial Time Delay	0 to 99 Sec
Trip Delay Time (Voltage, Current, Frequency, SSP, Unbalance)	0 to 999 Sec
Scrolling Time	1 to 99 Sec
Reset Time	0 to 99 Sec

**OUTPUT SPECIFICATION:**

Relay	2 Nos
Relay Type	1 <sup>st</sup> Relay ( NO - C - NC ) 2 <sup>nd</sup> Relay ( NO - C )
Rating	1 <sup>st</sup> Relay 10Amp, 250V AC 2 <sup>nd</sup> Relay 5 Amp, 250V AC


**AUXILIARY SUPPLY:**

Supply Voltage	100 to 270V AC, 50Hz
Power Consumption	4VA @ 230 AC MAX

**ENVIRONMENTAL CONDITION:**











Working Temperature	0 to 55 °C
Storage Temperature	0 to 55 °C
Relative Humidity	95 % RH Non-Condensing
Protection Level (As Per request)	IP-65 (Front side As per IS/IEC 60529 : 2001)

**TERMINAL CONNECTION**




## KEY OPERATION

### Operator Mode

To View Individual Parameters Value	 OR 
To Enter In Parameter Setting Mode	
To View The Voltage Page While Display Indicate fault	
To View The Current Page While Display Indicate fault	
To Reset The Relay Contact manually after Tripping	
To Scroll & Hold For 5 Second Press	 Scroll
<b>Parameter Setting Mode</b>	
Edited Parameter Value to be Set, And Move to the Next Step	
To Increment Parameter Value	
To Decrement Parameter Value	

## MECHANICAL INSTALLATION



1. Prepare the panel cutout with proper dimensions as shown above.
2. Fit the unit into the panel with the help of clamp given.
3. The equipment in its installed state must not come in close proximity to any heating source, caustic vapors, oil steam, or other unwanted process byproducts.
4. Use the specified size of crimp terminal (M3.5 screws) to wire the terminal block. Tightening the screws on the terminal block using the tightening torque of the range of 1.2 N.m.
5. Do not connect anything to unused terminals.

## MAINTENANCE

1. The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean soft cloth. Do not use isopropyl alcohol or any other cleaning agent.
3. Fusible resistor must not be replaced by operator.



## SAFETY PRECAUTION

Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

If all the equipment is not handled in a manner specified by the manufacturer, it might impair the protection provided by the equipment.



Read complete instructions prior to installation and operation of the unit.



**WARNING** : Risk of electric shock.

## WARNING GUIDELINES



**WARNING** : Risk of electric shock.

- 1) To prevent the risk of electric shock, power supply to the equipment must be kept OFF while doing the wiring arrangement. Do not touch the terminals while power is being supplied.
- 2) To reduce electro magnetic interference, use wire with adequate rating and twists of the same of equal size shall be made with shortest connection.
3. Cable used for connection to power source, must have a cross section of 1mm or greater. These wires should have insulations capacity made of at least 1.5kV.
- 4) A better anti-noise effect can be expected by using standard power supply cable for the instrument.

## INSTALLATION GUIDELINES

- 1) Do not allow pieces of metal, wire clippings, or fine metallic fillings from installation to enter the product or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
- 2) Circuit breaker or mains switch must be installed between power source and supply terminal to facilitate power 'ON' or 'OFF' function. However this mains switch or circuit breaker must be installed at convenient place normally accessible to the operator.
- 3) Use and store the instrument within the specified ambient temperature and humidity ranges as mentioned in this manual.

# FAULT MESSAGE

## Under Current fault Message

1) Unc in R Phase

r	→ Fault in R phase
U n C	→ Under Current
2.87	→ R phase Current Value

2) Unc in Y Phase

y	
U n C	
2.72	

3) Unc in B Phase

b	
U n C	
2.63	

4) Unc in RY Phase

r y	
U n C	
2.70	

5) Unc in YB Phase

y b	
U n C	
2.60	

6) Unc in RB Phase

r b	
U n C	
2.55	

7) Unc in RYB Phase

r y b	
U n C	
2.55	

## Frequency Fault Message

Over Frequency Fault Message

Under Frequency Fault Message

O u F	→ Over frequency	U n F	→ Under frequency
52.6	→ Frequency Value	48.6	→ Frequency Value

## Unbalance Fault Message

1) Unb in R Phase

r b	→ Fault Between R & B Phase
U n b	→ Unbalance
55	→ Unbalance Percentage Between R & B Phase

2) Unb in Y Phase

r y	
U n b	
59	

3) Unb in B Phase

y b	
U n b	
57	

4) Unb in RYB Phase

r y b	
U n b	
55	

## Phase Sequence Message

P H A	→ Phase
S E Q	→ Sequence
F L t	→ Fault

## Phase Loss Message

1) R Phase loss

r	→ R
P H A	→ Phase
L O S	→ Loss

2) Y Phase loss

y	
P H A	
L O S	

3) B Phase loss

b	
P H A	
L O S	

## Single Phase Prevention Fault

1) SPP in R Phase

r	→ R Phase Fault
S P P	→ Single Phase Prevention
100	→ R - Phase Voltage Value

2) SPP in Y Phase

y	
S P P	
105	

3) SPP in B Phase

b	
S P P	
110	

## SPP Fault Due to Phase Loss

1) SPP in R Phase

S P P	→ Single Phase Prevention
r	→ R Phase
L O S	→ Loss

2) SPP in Y Phase

S P P	
y	
L O S	

3) SPP in B Phase

S P P	
b	
L O S	

## Lock Rotor Point

1) LRP in R Phase

r	→ R Phase Fault
L r P	→ Lock Rotor Point
5.00	→ Phase Current Value

2) LRP in Y Phase

y	
L r P	
5.00	

3) LRP in B Phase

b	
L r P	
5.00	

## Neutral Loss Message

S P P	
r	
158	


NOTE : Neutral loss Protection available Only,  
In Case Of SPP Enable

3Ø - 4W NETWORK CONNECTION


3Ø - 3 W NETWORK CONNECTION

3Ø - 3W / 3 - 4W NETWORK CONNECTION


1) VLN Page




2) VLL Page




3) Amp Page




4) Frequency Page




1) VLL Page




2) Amp Page




3) Frequency Page



1) Fault Message




2) KA Page




WIRING CONNECTION

1) 3 Phase - 4 Wire



2) 3 Phase - 3 Wire



Password = 19 » Power On Time & ITD Time Selection  
 » Under Current, Over Current,  
 Under Voltage, Over Voltage,  
 Under Frequency, Over Frequency

Password = 39 » Network Selection & CT Ratio Selection





Password = 59 » Display Scrolling Time

Password = 29 » Single Phase Prevention (SPP)  
 Short Circuit, Lock Rotor Point,  
 Unbalance Current, Phase Sequence,  
 Phase Loss


Press **⏏** & **⏏** Key Together » Reset mode , Initial Trigger,  
 Relay Fault mode selection.

Long Press **⏏** Key to enter into Password

## PARAMETER SETTING



# PARAMETER SETTING



## NOTES

### Reset Mode:

- 1) If Reset Mode Selected is Manual, then the Fault will Reset Manually by pressing the Reset key on the instrument.
- 2) If Reset Mode Selected is Auto, then the Relay will be reset after Selected Reset time once the healthy condition achieved.
- 3) If Reset Mode Selected As ZVR (Zero Value Reset), then the Relay will be reset after Selected Reset time once the healthy condition achieved OR Zero Value reached.

### Initial Trigger:

- 1) If Initial trigger mode "I" is selected then Relay will start working once current is applied.
- 2) If Initial trigger mode "V" is selected then Relay will start working once Voltage is applied.


### Relay Fault:

- 1) If Relay fault selected is "off" than Relay will turn "off" when fault is achieved, otherwise Relay will remain turn "on".
- 2) If Relay fault selected is "on" then Relay will turn "on" when fault is achieved, otherwise Relay will remain turn "off".

**CONTROL FUNCTION**


**Under Current**

Power On:- 5 Sec  
Initial Time Delay:- 5 Sec  
Under Current:- Enable  
Under Current:- 3.0A  
Under Current time:- 5 Sec  
Relay Fault:- OFF  
Reset Mode:- Auto  
Reset Time:- 5 Sec



**Unbalance**


Power On:- 5 Sec  
Initial Time Delay:- 5 Sec  
Unbalance:- Enable  
Unbalance Percentage:- 50%  
Unbalance Time:- 5 Sec  
Relay Fault:- OFF  
Reset Mode:- Auto  
Reset Time:- 5 Sec



**Single Phase Prevention (SPP)**


(For Voltage)

Power On:- 5 Sec  
Initial Time Delay:- 5 Sec  
SPP:- Enable  
SPP Time:- 5 Sec  
Reset Time:- 5 Sec  
Reset Fault:- OFF  
Fault Reset mode:- Auto




**Under Voltage**

Power On:- 5 Sec  
Initial Time Delay:- 5 Sec  
Under Voltage:- Enable  
Under Voltage:- 380V  
Under Voltage time:- 5 Sec  
Relay Fault:- OFF  
Reset Mode:- Auto  
Reset Time:- 5 Sec



**Lock Rotor Point**

Power On:- 5 Sec  
Initial Time Delay:- 5 Sec  
Lock Rotor Point:- Enable  
Over Current:- Disable  
Lock Rotor Point:- 2.0  
Over Current Value:- 2.0A  
Relay Fault:- OFF  
Reset Mode:- Auto  
Reset Time:- 5 Sec



**Case-2**

